




German Tech Precision Manufacturing Co., Ltd

Installation and Operation  
Instructions ( manual )

For two-speed gearbox

2G250 / 2G300



Subject to technical change without notice.

Copyright by GTP, reproduction, in whole or in part, is only allowed with written  
authorization.

## Preface

1	Important Notes	3
2	Safety Notes	5
2.1	General introduction	5
2.2	Application	5
2.3	Delivery	5
2.4	Storage and start-up	6
3	Structure	7
3.1	Technical data	8
3.2	Installation positions	9
3.3	Main dimensions and models	10
3.4	Backlash	10
3.5	Lubrication	11
3.5.1	Splash lubrication	11
3.5.2	Recirculating lubrication	11
3.5.3	V1 / B5 Recirculating lubrication	11
3.5.4	Recirculating lubrication with heat exchanger	12
3.5.5	Lubricant	12
3.5.6	Ports and connections for initial fill/oil change	13
3.5.7	C.L.S. and connections at max. speed	13
3.6	Gearbox Shifting	15
3.7	Shift logic	17
3.8	Neutral shift logic	19
4	Installation and operation	22
4.1	Safety start	22
4.2	Before start	22
4.3	Before operation	22
4.4	Input	23
4.4.1	Adaption and assembling motor/gearbox	23
4.4.2	Pulley drive input	28
4.4.3	2G assembly instruction for adapter	29

---

4.5	Output	36
4.5.1	Pulley output (standard / long output)	36
4.5.2	Direct shaft output (inline/gear output)	36
4.6	Electrical connection, shifting	36
4.7	Shifter installation	37
4.8	Installation	41
4.9	Operation	41
5	Inspection and Maintenance	42
6	Fault checklist	43
6.1	Disassembly of gearbox	44
	Contact	45

## 1 Important Notes

Please observe the safety note in this manual!

	<b>SERIOUS DANGER</b> Can cause injury to personal and/or damage to property.
	<b>DANGER</b> Can cause slight or small injury.
	<b>HAZARDS</b> Can be harmful for the drive and environment
	Points and useful information.

### Caution and safety note



All users of GTP are responsible for their own work safety.

(All personnel in charge of assembly and operation have to be familiar and comply with all safety instruction, to avoid the injury to personal and/or damage to gearbox.)

(All personnel in charge of assembly and electricity have to be trained by GTP and make sure the proper operation of gearbox.)

(At any time the instruction need to be observed, for ensuring the correct operation and claim right within warranty period. Therefore, please read this instruction very carefully before commissioning!)

GTP cannot provide warranty, if any:

- Incorrect, improper use;
- Damage caused by using non-genuine parts or non-approved oil, or repair done by customer;
- Insufficient oil;
- Damage caused by accident or improper **transportation**;
- Out of scope of application;
- Defect or damage caused by motor(including belt), break off of the power transmission or defective of lubrication.

This instruction includes very important information about repair.  
Please keep it close to the gearbox.

In any case improper operation will make the warranty invalid even no description in this instruction!



Waste disposal, please observe current regulations.  
Uncollected cast, gears, shafts and bearings will be treated as scrap.  
Waste oil collection need to be treated according to local environment protection regulations.

## 2 Safety Notes



### 2.1 General introduction

During operation or after operation, surface of gearbox will generate high temperature.



Only qualified personnel can carry out the works as follows:

About transportation, storage, installation, connection, operation, maintenance and service, please read carefully below information and documents:



- Installation instruction
- Warning and notes on the gearbox
- Regulation and requirements for special system
- Safety regulation in the region and country

Personnel **will** be injured seriously due to below **reasons**:

- Use improperly or wrong installation or operation;
- Without authorization, disassemble the necessary protection cover or housing.



### 2.2 Application

The gearbox is designed for industry system, mainly for machine tool drives.

Please find technical data and information on the nameplate

It is very necessary to observe all the instruction!



### 2.3 Delivery

The shipment must be inspected for completeness and transport damages immediately after the delivery.

If damage is found, this must be communicated immediately to the transport company and confirmed by this company (may postpone the installation).

Please use proper and safe equipment to transport the gearbox.



## 2.4 Storage and start-up

Gearbox is designed with channel lubrication system. No oil inside the gearbox during transportation.

Store the gearbox long time or store in an improper environment (high humidity, sea freight,) can make the gearbox inside and outside rusty.

The gearbox is also useable for other systems which need torque increasing and/or speed reducing.


With different installation positions the gearbox can be used in Vertical Lathe and Horizontal B5, Vertical Machining center V1 or V3.

Before starting the gearbox, make sure oil channels are connected properly to avoid any damage due to wrong connection.

**Before powering up the gearbox, make sure that the oil path is connected correctly to avoid damage caused and the lubrication system is activated.**

### 3 Gearbox structure

Connecting parts	Input	Output	Shifting system
1.hub	6.sun gear	9.bearing housing	16.sliding sleeve
2.adpater plate	7.ring gear	10.11output bearing	17.shift fork
3.hub seal	8.ring gear bearing	12.output shaft	18.brake disc
4.hub bearing		13.radial shaft seal	19.shift unit
<b>Housing</b>		14.planet carrier	20.shift rack
5.Gearbox housing		15.sun gear bearing/ with cup spring	




### 3.1 Technical data

Type	2G250	2G300
Nominal power	Max.39kw	Max.47kw
Nominal speed	1500rpm	1500rpm
Nominal input torque	Max.250Nm	Max.300Nm $i = 5.50$ max.250Nm
Max. input speed $i \neq 1$	6300rpm	6300rpm
Max. input speed $i=1$	10000rpm	10000rpm
Max. output torque $i = 1.00$	250Nm	300Nm
$i = 4.00$	1000Nm	1200Nm
$i = 5.50$	1375Nm	1375Nm
Weight	About 69kg	About 93kg
<b>Motor dimension</b>		
h	132	160
d	42/48/55	55/60
l	110-0.2	110-0.2
b	230/250/300	300
e2	300	350
a1	-	-
s2	18	18

**Caution:**




Control braking time to ensure the brake torque should be less than the moments of inertia of gearbox.



### 3.2 Installation positions

**Horizontal B5 (fig 1, fig 2, fig 3)**

Fig 1



**Vertical (fig 4, fig5)**

Fig 4      Vertical V1



Fig 2




Fig 5      Vertical V3





Fig 3 Horizontal B5 rotate 90°

Shift unit on right side, gearbox turned 90° around axial (view to input end)



#### CAUTION

The breather outlet must always be at the top, regardless of the installation position.

### 3.3 Main dimensions and models

GTP two-speed gearbox 2G250/2G300 is useable as below models:

Input:

Motor is installed onto the gearbox by a flange.

Two sizes of motor: center height ( AH ) : (132mm and 160 mm).

Closed version (adapter plate delivered with. shaft seal 、 bearing and drive hub, if necessary adapter plate bearing can be taken away).

Output:

Standard design (belt output), design of bearing can allow high radial force.

Shaft output version

Inline output version

Inline CTS output version

**Shift unit can be mounted on the right/top side of the gearbox.**

### 3.4 Backlash

GTP two-speed gearbox 2G250 / 2G300 backlashes:

**20 arcmin** (measured on the output shaft, ambient temperature 20°C before starting the gearbox)

### 3.5 Lubrication

For the first starting of the gearbox, the correct level of the lubricating oil should be at the middle of the oil sight glass in accordance with the requirements of the operating manual.

The pump, oil tank and heat exchanger components must be arranged below the gearbox oil level.

Connecting an oil return with a proper angle assures smooth oil return.



#### 3.5.1 Splash lubrication

Splash lubrication is standard for GTP 2G gearbox B5 horizontal installation, it is applicable for high frequency gear shifting, varied operating speed and long standby time for tools changed.

The lubricated oil level should be in the middle of oil sight glass.

NOTE:

In case of oil sight glass is not visible when gearbox is installed on special angle, please take a tube with scale to replace oil sight glass.

#### 3.5.2 Recirculating lubrication

Continuous operation, or intermittent operation in the same gear for a long time running or high speed and short standby time must use this kind of lubrication mode.

For 2G250/2G300, the vertical V1 and the inverted V3 must be used with recirculating lubrication, and the arrangement of recirculating lubrication will be different according to the requirements of its operating temperature.

Some applications operate at low temperature require a suitable oil cooling system.

The application is various according to the different models of gearboxes.

In order to reach the best cooling performance of the gearbox and avoid affecting the lubrication, different oil ports and connection modes must be used according to the different installation positions and operation methods.

#### 3.5.3 V1 / B5 Recirculating lubrication

Take out the oil plug and connect the oil inlet pipe.

**The volume of lubricating oil is in total 2.5 liters / minute.**

Remove one of the sight glass and connect the oil outlet pipe, the screw size (M42x1.5).

To maintain oil running smoothly and avoid hot oil stay inside of the gearbox (pipe diameter at least 20mm).

### 3.5.4 Recirculating lubrication with heat exchanger

The recirculating lubrication system with heat exchanger can ensure further reduction of the oil temperature.

The size of the oil tank should be at least 10 times of requested circulating oil volume or 20 liters

**GTP recommends to install an oil level sensor in the auxiliary tank and avoid damage to the gearbox due to lack of oil.**

Install a filter( $60 \mu\text{m}$ ) and a safety valve at oil inlet pipeline.


The oil return pipe should be located lower than the gearbox oil outlet, in order to prevent the oil level rising in the gearbox.

### 3.5.5 Lubricant

	Description	Application	Remarks
Gearbox oil	HLP68 to ISO VG68	Splash lubrication (depending on installation position)	
	HLP46 to ISO VG46		Also for recirculating without lubrication heat exchanger
	HLP32 to ISO VG32	Recirculating lubrication with heat exchanger	
	HLP22 to ISO VG22		

### 3.5.6 Ports and connections for initial fill/oil change

Installation Position	Inlet ports	Outlet ports
V1	I	N-shaft output
V3		P-flange output
B5		H
B5 rotate		G,F,H
		D



### 3.5.7 C.L.S. lubrication system and ports connection at max. speed

Connecting K or R to an integral lube oil system is mandatory in applications with maximum speeds of 10,000 rpm or with a CLS lubrication system.

Furthermore, a gearbox oil cooler **>0.3 kW** and a circulating oil volume of **>20 liters** is required.

When using the gearbox at max. speed:

- Please make sure to connect M and K (or L), oil quantity should be 3 liters/min, oil pressure should be 3 bar,
- If space is enough for using M, K and L together as oil inlets, oil quantity should be 2.5 liters/min, oil pressure should be 2.5bar.
- All types include oil inlet K/R with internal lubrication hole. Pay attention to the corresponding type number (Selection no.) for the C.L.S. integral lube oil system when ordering.



The principle factor in determining the oil supply volume is always the volume that flows out of the oil return.


If lubricating system is not able to use K, R/L as oil inlets, the C.L.S. cannot be used, and also max. speed is not reachable.

Installation position	Inlet ports	Max. pressure	Outlet ports
V1/B5	<b>K or R</b> ( 1.5 dm <sup>3</sup> /min) <b>M</b> (approx. 1.0 dm <sup>3</sup> /min)	1.5 bar	D or E
V3	<b>K or R</b> (1.5 dm <sup>3</sup> /min) <b>M</b> (1.0 dm <sup>3</sup> /min)	1.5 bar	H
B5 rotate 90°	<b>K or R</b> (1.5 dm <sup>3</sup> /min) <b>M</b> (1.0 dm <sup>3</sup> /min)	1.5 bar	H



Example of connections for recirculating lubrication of gearbox horizontal position

1. Oil cooler
2. Oil pump
3. Oil Outlet (E )
4. Oil Inlet (M)
5. Oil Inlet (K)
6. Oil flow rate and pressure sensor



### 3.6 Gearbox shifting

Pin 2 and Pin 3 will be affected by 24 V voltage and rotating direction is defined by the applied polarity.

During the shafting, make sure the spindle motor shaft oscillating  $\pm 5^\circ/\text{s}$ .

Angle[ $^\circ/\text{sec}$ ]	Speed[rpm]	Time[sec]
5	1.00	0.83
	2.00	0.42
	3.00	0.28
	4.00	0.21
	5.00	0.17

## Structure




Limit switch control current : 0.1 – 0.5 A  
Chang over control current : 5 A.

If the limit switches detect, gears are no longer securely engaged, emergency shut-off must be initiated through the control system.  
Electromagnetic fields can falsify the limit position monitoring currents. This can be prevented by rerouting or shielding the circuit.

Diagram for shift unit with two positions:

1<sup>st</sup> gear ==>e.g. 4:1

2<sup>nd</sup> gear =




The shifter of gearbox is driven by 24V DC motor.

<b>plug configuration Harting Han8U without Neutral position</b>		
	cable color	2G120 / 2G121 / 2G250 / 2G300
Pin 1	brown	grounding housing
Pin 2	red	motor + ; + 24V DC ; min. 2.5A
Pin 3	black	motor - ; - 24V DC ; min. 2.5A
Pin 4	green	signal S1- Position
Pin 5	blue	power supply micro switch ; 24V DC ; max.1.5A
Pin 6	white	signal S2- Position
Pin 7	not used	not used
Pin 8	not used	not used


### 3.7 Shift logic

S1 → S2 (Low gear to High gear)



## Structure

## S2 → S1 (High gear to Low gear)



### 3.8 Neutral shift logic

To switch from S1 to neutral (N), pin 1 is positive and pin 2 negative.  
To switch from S2 to N, the polarity must be inverted.



**Gear change can only be done idleness (max. 5 rpm) and unencumbered.**

Switching operation:

Status: gear stage S1:

- gear ratio  $i = 4.0 / 5.5$
- signal S1 is active (low)

Status: gear stage S2:


- gear ratio  $i = 1.0$
- signal S2 active (high)

Status: neutral (N):

- input and output shaft are not keyed and can be pivoted
- signal N active (high)


With starting the gear change, input and output shaft have to be idleness (max. 5 rpm) and unencumbered. Alternatively, the main spindle motor can make the shaft oscillate  $\pm 5^\circ$  at a rate of 1 to 5 rotation directions per second.

## Neutral shift logic



plug configuration Harting Han8U with Neutral position		
	cable color	2G250 / 2G300
Pin 1	brown	grounding housing
Pin 2	red	motor + ; + 24V DC ; min. 2.5A
Pin 3	black	motor - ; - 24V DC ; min. 2.5A
Pin 4	green	signal S1- Position
Pin 5	blue	power supply micro switch ; 24V DC ; max.1.5A
Pin 6	white	signal S2- Position
Pin 7	yellow	signal N- Position (closer)
Pin 8	grey	micro switch

## Shift logic -Neutral position



## 4 Installation and operation

### 4.1 Safety start



Please observe all the regulations about safety and accident prevention in the country or region. Only qualified personnel can carry out the installation and starting up.

Improper operation or use can cause serious injury or property loss.

GTP will not be responsible for the results due to wrong operation.



### 4.2 Before start

Please check the gearbox carefully and make sure no technical defect before installation.

Gearbox can be installed only under below conditions:

- Technical data on the purchasing order is the same as the nameplate;
- No damage on the gearbox;
- Can rotate the gearbox shaft by hand;
- Clean oil pipe, enough oil quantity and oil pressure;
- All the electrical wires no damage.

### 4.3 Before operation



Must clean the antirust agent, dust or other contaminant(use standard agent). Keep the agent away from seal lip, it will damage the material!

## 4.4 Input


According to specific requirements GTP can provide different input versions.


### 4.4.1 Adaptation and assembling motor/gearbox

Different connection parts are used depending on the motor size

To ensure faultless function, the input hub must be mounted on the right position, therefore compliance with reference dimension "D" is necessary.

Gearbox 2G250/2G300 D value :124.8~125.0mm





### Measurement of motor tolerance

Gearbox type	tolerance			
	<b>A</b>	<b>B</b>	<b>C</b>	<b>L=140</b>
2G250/2G300	0.025	0.063	0,063	$\pm 0,200$
Tolerances A,B,C according to DIN 42955R				
Please note that the tolerance of the shaft length "L" is restricted in relation to the DIN standard!				

### Motor tolerance




The tolerance for motor shaft length "L" must be conformed to the specification to ensure the normal operation of gearbox.


In case of oversize shaft, it must be machined to the correct tolerance. For undersized shaft, take shims to compensate it.

**4.4.1.1 Balancing** There are two balancing types for the motor and gearbox: half-key and full-key (DIN ISO 8821).

The hub is balanced without key. It must be ensured that the motor is balanced with full key. This is based on the original key.



Half-key balancing




Full-key balancing

### Motor output shafts with standard fitted key

Motor shaft diameter	Fitted key	Fitted key length
48mm	A14x9	90mm
55mm	A16x10	90mm
60mm	A18x11	125mm
42mm	A14x9	90mm

#### 4.4.1.2 Closed design with hub and shaft seal



2G250/300 standard version is closed. Due to different motor types, the center heights are different, therefore, using different adapter plate(5) with seal(7) is necessary.



**The reference dimension “D” is important for gearbox operating. D value is 124.8~125.0mm.**

Hub (1) and adapter plate (5) are not fixed with gearbox while transportation. Before installation, please clean the fitting surface of motor flange(3), hub(1), adapter plate(5) and gearbox.

Refer to the page 23 to check the “A”, “B” and “C” values, then apply grease to the motor shaft lightly.

Adapter plate(5) with seal(7) is pre-installed to the motor shaft, fix it by bolts, then install gearbox.



**Apply grease to seal (7) and hub (1) completely before installation, check and make sure the seal(7) and its lip are in the correct position during installing processing.**

After cleaning, heat the hub (1) opening side to about 120° C, then insert it to motor shaft until it cannot moved anymore.



**The motor shaft will be damaged if the hub heating is not successful.**


Recheck reference dimension “D” (as shown in page 22). Tighten the threaded pin (9) and secure it to prevent it from turning

Depending on the used specification, an O-ring or sealing compound is used to tighten the gearbox against the adapter plate and the adapter plate against the motor flange. Using the O-ring, it has to be coated with grease before being inserted into the seal groove.

Check the right position. Using sealing compound, observe manufacturers instructions

Check the position of the gearbox shifting mechanism.

The sliding sleeve must be in gear position S1 ( $i \neq 1$ ).



Take up the gearbox and place it onto the adapter plate.

Carefully bring the sun-hub-connection together when doing this.

This can be made easier by turning to the left and right at the gearbox output.

Gearbox housing, adapter plate and motor are bolted together using four or eight bolts, quality 8.8 or higher

## 2G250/300 HUB spacer thickness calculation

A = HUB length

C = HUB bore depth


S = spacer thickness

Step :

1. measuring A value
2. measuring C value
3. mounting adapter plate to motor flange
4. measuring adapter to motor shaft end be E
5. calculating the spacer thickness

$$S = 125 - (A - C + E)$$

6. Insert the spacers into HUB , heat HUB , mount the heated HUB onto motor shaft
7. Checking the D value, it must be between 124.80 ~ 125.00mm



#### 4.4.2 Pulley drive input(flange input)



Flange input is a special version and connected with pulley drive to the motor shaft. The pulley must be in the center of the outer diameter of the input flange, bolts tightening according to specified torque for friction engagement and fixing.

According to VDI Directive 2060, pulley drive should be balanced in quality 6.3 to ensure lower vibration operating.




**Tighten the belts with specified tensioning force to avoid overload on bearing.  
The belt stress must be equally between the bearings.**

#### 4.4.3 2G assembly instruction for adapter



### A 公差量測

Tolerance A motor run out checking



### B 值檢查

Tolerance B checking



### C 公差檢查

Tolerance C checking



### 清潔 HUB 內部及 端板法蘭面

Clear HUB inner and adapter plate  
surface .



馬達軸心塗抹  
適量的黃油保護馬達軸心  
於拆裝過程中減低損傷

Lubricate the shaft surface  
with grease for protection.

黃油規格

*Grease spec. reference*

- SHELL Avania grease HD2
- SHELL Avania WR2
- ESSO Beacon EP2
- FUCHS Renolit CXEP2



拆下 HUB 定位  
螺絲

Remove HUB  
screw .



加熱 HUB 內部至  
120°C  
Heat HUB to 120°C


注意：  
不可直接對端板  
油封加熱  
Attention ,  
No direct to heat on  
the seal .



施力在HUB 前端 ,  
將端板推到與馬達端面  
密合  
不可施力在端板上

To assemble adapter plate  
to motor shaft . Push only  
on the hub and not on the  
Plate .





### 安裝尺寸檢查

Measure the correct HUB position

使用深度規，量測 HUB 頂端到

馬達端面距離 D 值

Set depthgage measure the dimension D

HUB top to adapter surface



Gearbox	Dimension D mm
2G250	125-0.2
2G300	125-0.2

## 4.5 Output

GTP two-speed gearbox 2G250/300 have two types of output.



### 4.5.1 Pulley output (standard / long output)

Pulley must be fixed at the center of flange (tolerance K6) outer diameter, fixing bolts tighten according to tightening torque.

**The length of bolt shall be calculated to avoid excessive contact with the output shaft cover**

Balanced level is 6.3 to ensure low vibration running

When strain the belt, please be aware of the maximum tension to avoid bearing overload. Belt stress must be evenly between the two bearings of output shaft.



### 4.5.2 Direct shaft output (inline / gear output)

Please pay attention on balancing method while using direct shaft output, Gearbox output shaft is full-key balancing when it is delivered.

## 4.6 Electrical connection, shifting

The gearbox is electrically connected using the supplied 8pole Harting connector (HAN 8 U).

Shift unit Technical data :

Power: 120W

Voltage: 24 V DC  $\pm$  10%

Current: 5 A

Required cable cross-sectional diameter: 1.5 mm<sup>2</sup>.




The 24 V DC connection voltage and 5 A power consumption must be assured on the shift unit connector. Losses due to cable length and transition resistors must be taken into account.

We recommend using a separate power supply to assure the stability of power.

#### 4.7 Shifter installation




Do not energize the shifter before installing the gearbox.




- i** Before take out shifter from gearbox or insert onto gearbox  
MUST ensure the shifting stays in (low gear)
1. Use a T2.5 wrench to remove the 3 screws on the outer cover of the shifter.





2. Remove the fixing screw of the shifter plug Silk (M3X10)


**3. Install O-ring**

(Before installing O-rings, please Apply Vaseline or butter to the O-ring, Ensure that the O-ring can better adhere to the shifter

**4. Apply an appropriate amount of 243 screw glue on the fixing screw of the shifter.****5. Install into the hole on the casing and tighten the screws**

**!** When locking, make sure the O-ring is not pressed

	<p>6. Locking set screw torque 23Nm</p> <p><b>i</b> When locking, make sure to avoid wires</p>
	<p>7. If it is found that the gear signal contact is not in the center of the gear cam, the cam position must be adjusted.</p> <p><b>i</b> There is a signal on the side of the gear switch One click is the low-range switch The two dots are high-end switches</p>
	<p>8. Shift to low gear first, check and then adjust. Loosen the gear cam fixing screw to adjust.</p>



9. Then shift to high gear, check and adjust



10. Install the cover



11. Fixed the gear shifter plug and completed



## 4.8 Installation

Installation position of GTP two-speed gearbox 2G250/2G300 is B5/V1/V3。

Shift unit can be located on the left side, right side or top of the gearbox.

The breather outlet must always be at the top, regardless of the installation position.



When install the motor onto the gearbox, support B side of the motor to reduce the vibration. When assembly make sure no blockage on the fan. Oil is out of supply scope. Before starting the gearbox, please assure enough oil quantity and oil pressure.

Input flange, output flange and output shaft rotate at a very high speed, must provide proper protection cover, otherwise there will be danger of injury!



## 4.9 Operation

Gearbox has to be checked about function. When check the function, need test the gearbox at both of the directions and ratios.

Shift unit also need to be tested.

## 5 Inspection and maintenance

Frequency	Content
Every day:	<ul style="list-style-type: none"><li>- check the oil channels and oil control system</li></ul>
Every week:	<ul style="list-style-type: none"><li>- check the oil level of gearbox</li><li>- check the oil quantity(visually)</li><li>- check the filter</li><li>- check the leakage of the gearbox</li></ul>
After 2,000 working hours or every six months	<ul style="list-style-type: none"><li>- change the oil</li><li>- check the oil channel and control system</li></ul>



Intervals for check and maintenance must be kept.

It may cause damage on the bearing or gear if don't comply with above description about check and maintenance.



Check and maintenance can be only carried out when the gearbox cool down. Hot oil may cause injury.

## 6 Fault finding and Tips

Fault	Cause of fault	Tips
Gearbox is loud, running noise	a) engaging/friction noise: bearing damage b) Knocking noise: drive mechanism is asymmetric. c) Rotating noise: wrong installation of output shaft.	a) contact GTP service. b) contact GTP service. c) Mount the output shaft onto the spindle correctly, careful about second damage.
Abnormal, irregular noise	Foreign object in the oil.	- Check the oil - stop the gearbox and contact GTP service.
Oil leakage at a) gear cover b) sealing	a) rubber seal of the gear cover has a leakage b) sealing defect c) oil cannot return to oil cooler.	a) Tighten the screw between gear cover and gear, if still leakage please contact GTP service. b) Contact GTP service. c) Check the oil quantity and remove the foreign object, if still leakage please contact GTP service.
Motor or input shaft rotate, output shaft cannot rotate.	a) Connection between shaft and hub is interrupted.	Return the gearbox to the manufacturer.


## 6.1 Gearbox - disassemble



- Stop the machine
- Stop the power supply
- Disconnect the electrical plug
- Drain the gearbox oil and disconnect the gearbox oil pipes
- Remove the bolts (11)
- Pull the gearbox (6) off the adapter plate (5) and hub (1)

Hub:

- Screw off the pin(9)
- Using the three arm puller and remove aid(12) to pull off the hub until it is separated from motor shaft.



After disassembly renew the hub seal disc and o-ring  
Before installing clean and coat the sealing edge with liquid seal.

---

**If you need technical service please inform us below information:**

- Contact email, tel and fax number
- Technical information on the name plate (complete)
- Defective type
- Time and details about the fault
- Possible reasons

**Contact:**

**German Tech Precision Manufacturing Co., Ltd**

No. 10-3, Ln. 358, Sec. 1, Hemu Road, Shengang Dist.,  
Taichung City 429012, Taiwan (R.O.C.)

Tel: +886 (4) 2515 0566\*509

Fax: +886 (4) 2515 2413

E-mail: marcolin@zfgta.com.tw

Website: <http://www.german-tech-precision.com/>

**Chief Representative in P. R. China:**

**Shanghai ZhiShun Trading Co.,Ltd**

Floor 2, Building 3, No.398, Songying Road, Qingpu District, Shanghai, P .R . China

Post code: 201706

Tel.+86-021-59883978

Fax.+86-021-59883979

E-mail: sales@zhishuntrade.com

Website: [www.gtadtc.com](http://www.gtadtc.com)